Master Format #: 03 33 00

# **INCRETE UNI-STRIPP**

# EUCLID CHEMICAL

# **UNIVERSAL STRIPPER FOR ALL PAINTS AND COATINGS**

# **PACKAGING**

1 gal (3.8) and 5 gal (18.9 L) units

### **YIELD**

50 ft²/gal @ 1/32 in (1.22 m²/L @ 0.78 mm)

# **APPEARANCE**

Opaque gel

# **CLEAN UP**

Clean tools and equipment with INCRETE SOLV-KLEEN before material dries. Control waste runoff.

# **SHELF LIFE**

3 years in original, unopened container

# SPECIFICATIONS AND COMPLIANCES

Viscosity: 60 KU @ 70 °F (21 °C)

# **BRIEF OVERVIEW**

INCRETE UNI-STRIPP universal stripper is designed to remove a wide variety of paints, stains, and varnishes which are oil or water-based, including latex alkyds, stains, enamels, lacquers and clear paints. Unlike other paint removers, INCRETE UNI-STRIPP can remove difficult coatings such as two-component epoxy or urethane sealers from concrete surfaces. INCRETE UNI-STRIPP is also very effective on mastic adhesives and glues.

# PRODUCT CHARACTERISTICS

# **ADVANTAGES**

- Citrus scented
- Can remove multiple layers
- Can be cleaned with water
- Thick enough to use on vertical surfaces

# **COMMON USES**

- Interior/Exterior
- Horizontal, vertical, overhead
- Remove sealers, paints & coatings
- Removes most glues and mastics

### **COMMON METHODS**

- Brush
- Roller
- Trowel
- Squeegee

# **DIRECTIONS FOR USE**

INCRETE UNI-STRIPP is ready to use. A small test patch should be applied to the coated surface to determine the dwell time needed to soften and remove the coating. Shake or mix prior to use. Application can be by brush, roller or trowel. INCRETE UNI-STRIPP may be worked in with a stiff bristled broom for added effectiveness. Normally two-component epoxy systems need an extended dwell time. Thermoplastic acrylics often require less than 30-minute dwell times. For best results cover all applications with plastic sheeting and remove any trapped air. Loosened coatings can then be scraped or rinsed with a power washer. Control waste/runoff in accordance with local environmental guidelines.

# PRECAUTIONS/LIMITATIONS

- Use with adequate ventilation.
- For professional use only.
- In all cases, consult the Safety Data Sheet before use.

